

ODOT-PNM02 V2.0

Protocol Converter

User Manual

V1.7

2022.02.08

Modbus-RTU/ASCII or Non-standard protocol to ProfiNet Converter



Odot Automation System Co., Ltd.

2018-03

Copyright ©2019 Odot Automation all rights reserved

Version Information

The document has the following modifications:

Date	Version	Modify content	Author
20180301	V1.0	release version	CCL
20180801	V1.1	update content	CCL
20190520	V1.2	Added related descriptions used in Step7	LJP
20190924	V1.3	Freeport mode added	CCL
20191118	V1.4	Added the application of Freeport mode in TIA/STEP7 V5.5/STEP 7-MicroWIN SMART	CCL
20200722	V1.5	Product hardware upgrading, hardware description update.	CCL
20200824	V1.6	The free transparent transmission mode of the master and slave is changed to two independent serial ports	CCL
20220208	V1.7	hardware revision	CCL

Ownership rights information

Without the permission of the copyright owner, all or part of this document shall not be republished as a paper or electronic document.

Disclaimer

This document is only intended to assist the reader in using the products, and the company shall not be responsible for any loss or error caused by the use of the information in this document. The product and text described in this document are under constant development and refinement. Odor Automation System Co., Ltd. has the right to modify this document without notifying users.

Software download

Please log on the official website: www.odorautomation.com and click on the corresponding product page to download.

Revision description:

1. GSD file 20190312 and above, in gateway slave mode: To avoid the problem of address overlap when customers use Area 0 and Area 4 to output data, pls use Area 1 and Area 3 for PN output data, and Area 0 and Area 4 for input data.
2. GSD file 20190312 and above versions are applicable to ABB Profinet master system.
3. Firmware V1.6 and above version add function: when the gateway works in transparent transmission mode, When the serial port selects the master-slave response mode, it also supports the active data reporting function.
4. ODOT-PNM02 V2.0 hardware revision, and the two serial ports could independently set working mode, but the converter function does not support IRT and MRP.

Disclaimer of Warranties

Product Usage

NOTE
• WHEN INSTALLING, OPERATING, AND MAINTAINING THE EQUIPMENT, DO NOT EXCEED ANY OF THE RATINGS SPECIFIED IN THE ELECTRICAL CHARACTERISTICS; • WHEN INSTALLING, OPERATING, AND MAINTAINING THE EQUIPMENT, DO NOT EXCEED ANY OF THE RATINGS SPECIFIED IN THE ENVIRONMENTAL CHARACTERISTICS. DO NOT USE THE PRODUCT IN THE FOLLOWING PLACES: PLACES WITH DUST, OIL FUMES, CONDUCTIVE DUST, CORROSIVE GASES, AND FLAMMABLE GASES; DO NOT EXPOSE TO HIGH TEMPERATURES, CONDENSATION, WIND AND RAIN; VIBRATION AND SHOCK WILL ALSO CAUSE DAMAGE TO THE PRODUCT; FAILURE TO FOLLOW THE INSTRUCTIONS MAY RENDER THE PROTECTION PROVIDED BY THE DEVICE NULL AND MAY RESULT IN MINOR BODILY INJURY OR DAMAGE TO THE DEVICE.

Disclaimer of Warranties

The Company shall not be liable for any damage or malfunction of the equipment caused by:

1. Transportation damage: equipment damage caused by improper transportation or packaging;
2. Natural factors: damage caused by lightning strikes, voltage fluctuations, water ingress or natural disasters (such as fires, floods, etc.);
3. Improper use: damage caused by overload, non-standard operation, unauthorized modification or use of unqualified accessories;
4. Unauthorized maintenance: equipment failure caused by unauthorized

maintenance or alteration;

5. Other non-product reasons: damage caused by other reasons that have nothing to do with the equipment itself.

Repair services

1. For the damage caused by the above reasons, the company will charge the repair fee according to the actual situation.

2. Outside the warranty period, the company provides paid maintenance services, and the cost is charged according to the maintenance situation.

Assumption of Risk

The company shall not be liable for casualties, property damage or other related losses caused by the use of the equipment. All risks are borne by the user.

catalog

ODOT-PNM02 V2.0.....	1
Protocol Converter.....	1
1.product description.....	8
1.1 Product Features.....	8
1.2 The main technical parameters	9
1.3 Technical parameters.....	10
2.Hardware description	12
2.1 Appearance.....	12
2.2 Indicator LED description.....	14
2.3 Terminal definition.....	14
2.4 External terminal resistance	15
2.5 Installation size	16
3. Product application	17
3.1 Converter working mode	17
3.2 Converter Default Parameters.....	17
3.3 Converter read and write command module.....	19
3.4 Converter application topology.....	29
4.Appendix.....	90
4.1. Modbus-RTU Introduction to Agreement.....	90
4.2 Modbus Storage area.....	90
4.3 Modbus function code.....	90
5.Brief introduction of serial network topology	97
5.1 RS232.....	97
5.2 RS422.....	98
5.3 RS485.....	100

1. Product description

1.1 Product Features

ODOT-PNM02 V2.0 gateway is a Modbus-RTU/ASCII or non-standard protocol to ProfiNet protocol converter. It can realize the conversion from Modbus-RTU/ASCII or non-standard protocol to ProfiNet. Any device with RS485/RS232/RS422 interface supports Modbus-RTU/ASCII or non-standard protocol can use this product to realize interconnection with industrial bus ProfiNet. Such as: PLC, DCS, remote IO, VFD, scanner, motor start protection device, intelligent high and low voltage electrical appliances, electricity measuring device, intelligent field measuring equipment and instruments, etc.

Notice:

The product marked as **ODOT-PNM02**, and the GSD file uses the GSD configuration of **PNM02 V1.5** in GSDML-V2.33-ODOT-PNM02-20191008.xml.

The product marked as **ODOT-PNM02 V2.0** and the GSD file uses the GSD configuration of **PNM02L V2.0** in GSDML- V2.33-ODOT-PNM02-V2.0.

The product marked as **ODOT -PNM02 V2.1**, and the GSD file uses the GSD configuration of **PNM02L V2.1** in GSDML- V2.33-ODOT-PNM02-V2.0.

1.2 The main technical parameters

- ◆ Installation method: 35mm standard rail installation
- ◆ Dimension: 110*110*27.5mm
- ◆ Support standard ProfiNet I/O Device V2.3
- ◆ Profnet data area: The max input is 1440 bytes, and the max output is 1440 bytes.
- ◆ It supports RT (synchronization), does not support IRT (isochronous synchronization), MRP (media redundancy protocol), and MRPD (media path planning redundancy) functions.
- ◆ Maximum slots: 50
- ◆ Serial port isolation: optocoupler isolation, power isolation
- ◆ Number of serial ports: support dual serial port RS485/RS232/RS422, 2 Serial ports work independently.
- ◆ Serial port terminal resistance: an external 120Ω resistance is required.
- ◆ Serial protocol: Supports Modbus-RTU/ASCII Master, Modbus-RTU/ASCII Slave and free port transparent transmission protocol.
- ◆ Serial port parameters: Support 1200-115200 baud rate, support none, odd, even parity
- ◆ Number of Modbus stations supported by serial port: 50 (limited by slot)
- ◆ Support Modbus function code: 01/02/03/04/05/06/15/16
- ◆ Power supply: 19.2~28.8VDC input, nominal 24VDC
- ◆ Operating temperature: -40~85°C
- ◆ environment humidity: 5%-95%(No condensation)
- ◆ Protection level: IP20

1.3 Technical parameters

General Parameters	
Module Description	Modbus or private protocol to Profinet protocol converter
Power supply	19.2-28.8VDC (nominal: 24VDC)
Power protection	Anti-reverse protection
Power consumption	Max.86mA@24VDC
Isolation	The isolation voltage between system power and PE is AC 500V The isolation voltage between I/O channel and PE is AC 500V The isolation voltage between system power and I/O channel AC 500V
Power wiring terminal	2*3P Spring terminal
Wiring	Max.1.0mm²(AWG 17) Min.0.2mm²(AWG 24)
Size	110*30*80mm
Installation	35mm DIN-Rail
Weight	130g
Weight	aluminum alloy
Operating Temperature of Vertical Installation	-40~85°C
Operating Temperature of Horizontal Installation	-40~75°C
Relative Humidity	5%~95%RH, no condensation
Storage Temperature	-55°C~125°C
Storage Humidity	5%~95%RH, no condensation
Manufacturing Test Temperature	-40°C~75°C
Ingress Protection Rating	IP20
Vibration Resistance	Comply with IEC 61131-2、IEC 60068-2-6 standards
Impact Resistance	Comply with IEC 61131-2、IEC 60068-2-27 standards
EMC Performance	Comply with IEC 61131-2、IEC 61000-4 standards
Ethernet Parameters	
Number of Network Ports	2*RJ45 (Port1、Port2)
Protocol	PROFINET
Standard Protocol	ProfiNet I/O Device


Network parameter	10/100Mbps, Self-adaption, Full-Duplex
Data Area	a maximum of 1440 bytes for input and 1440 bytes for output
Default IP Address	192.168.0.254
Default Devices Name	pnmb-address
RT	Supported
IRT	Not supported
MRP	Not supported
MRPD	Not supported
Downward Compatibility	Not supported
Serial Port Parameters	
Number of Serial Port	2 *RS485/RS232/RS422
Wiring Terminal	16P Spring wiring terminal
Protocol	Modbus RTU/ASCII, Private protocol
Working mode	Modbus Master Modbus Slave Freed mode (Report, Request-Response)
Serial port independently	The two serial port work independently
Serial port parameters	300~500000bps None parity, odd parity, even parity
Terminal Resistance	An external 120Ω terminal resistor is required
Number of Modbus slave	50 (Limited by the TIA slot)
Number of read/write commands	50 (Limited by the TIA slot)
Modbus Function Code	01 / 02 / 03 / 04 / 05 / 06 / 15 / 16
Update Software	Firmware Update Tool (network port, serial port)

2. Hardware description

2.1 Appearance



The upper panel has two ProfiNet interfaces and power connection terminals. PORT1 and PORT2, the two interfaces have the same function. These two interfaces have the switch function, that is, the host computer can access the equipment connected to PORT2 through the PORT1 interface, as shown in the figure below (the computer IP is 192.168.1.92, the computer is connected to the PORT2 port, Siemens S7 -1200 connects to PORT1), the upper computer software can search for devices in the same ProfiNet Network.



2.2 Indicator LED description

The equipment has 6pcs of LED status indicators, the symbol definition and status description are shown in the table below.

Symbol	Definition	Status	Description
PWR	Power indicator	Red light is on	power supply on
		Red light is off	Power is not connected
DF	Device status indication	Red light is on	Device failure
		Green light is on	Device is normal
SF	System status indication	Red light is on	system error
		Red light flashing	Lighting test
		Red light is off	System is normal
BF	Bus status indication	Red light is on	The network cable is not connected
		Red light flashing	The bus configuration is not configured
		Red light is off	Bus is normal
CO1	Serial port 1 status indication	Green light Flashing	Serial port 1 has data transmission and reception
		Green light is off	Serial port 1 has no data transmission and reception
CO2	Serial port 2 status indication	Green light Flashing	Serial port 2 has data transmission and reception
		Green light is off	Serial port 2 has no data transmission and reception

2.3 Terminal definition

The equipment wiring adopts 6Pin 3.81mm pitch plug-in terminal. The terminal definition of RS485 interface is shown in the table below.

Serial number	Mark	Wiring definition		
		RS485	RS232	RS422
1	1TA+	Serial port1 (A+)		Serial port1 (TX+)
2	1TB-	Serial port1 (B-)		Serial port1 (TX-)
3	1R+			Serial port1 (RX+)
4	1R-			Serial port1 (RX-)
5	GND	Common ground (signal ground)		
6	1TX		Serial port1 1 (TX)	
7	1RX		Serial port1 1 (RX)	
8	PE	Shield ground		

9	2TA+	Serial port 2 (A+)		Serial port2 (TX+)
10	2TB-	Serial port 2 (B-)		Serial port2 (TX-)
11	2R+			Serial port2 (RX+)
12	2R-			Serial port2 (RX-)
13	GND	Common ground (signal ground)		
14	2TX		Serial port 2 (TX)	
15	2RX		Serial port 2 (RX)	
16	PE	Shield ground		

The definitions of power wiring terminals are shown as below:


No.	Termials	Definitions
1	PE	Grounding
2	V-	24Vdc-
3	V+	24Vdc+

2.4 External terminal resistance


According to the actual situation on site, a 120Ω terminal resistor needs to be connected to the serial port of the gateway. The RS485 bus supports a maximum of 32 nodes without relays. The nodes are connected by a "daisy chain" connection.

Terminal resistors are required at both ends of the communication cable, and the resistance is required to be approximately equal to the characteristics of the transmission cable. impedance. In short-distance transmission, termination resistors are not required, that is, termination resistors are generally not required below 300 meters. The terminating resistor is connected to the two ends of the transmission cable. When the gateway is applied in the field, if the field RS485 bus is far away and the field interference is large, it is necessary to add 120Ω terminal resistance at both ends of the RS485 bus to prevent the reflection of the serial signal.

Note: The 120Ω resistor is attached in the box, please check it.



2.5 Installation size



3. Product application

3.1 Converter working mode

Each serial port of the converter has 3 working modes: Modbus master, Modbus slave, and free port transparent transmission mode.

When the serial port works in master mode and the serial port can connect up to 31pcs of Modbus RTU/ASCII slave devices. This mode is mainly used for data communication between ProfiNet master and Modbus RTU/ASCII slave.

When the serial port works in slave mode and the serial port can be connected to 1pc of Modbus RTU/ASCII master device. It could realize the data communication between ProfiNet master and Modbus RTU/ASCII master.

If the serial port works in free port transparent transmission mode, and this serial port can be connected to 1pc of serial port device. It could realize the data communication between ProfiNet master and serial port device.

3.2 Converter Default Parameters

ProfiNet configuration parameter:

The default IP address of converter is 192.168.0.254 and the default device name is pnmb-address. It needs to change the device name during application. During configuration, please ensure that the configured device name is the same as the actual device name.

Serial port configuration parameters:

Note: M indicates that the parameter is valid in the master mode, S indicates that the parameter is valid in the slave mode, and F indicates that the parameter is valid in the free port transparent transmission mode.

M/S/F: gateway mode: Modbus master, Modbus slave, and free free port transparent transmission are Optional. The default is Modbus master.

M/S/F: baud rate. It can select standard baud rate or customized baud rate. Default value: standard baud rate.

M/S/F: standard baud rate. Serial port baud rate, 300-500000bps is optional. The

default value is 9600bps.

M/S/F: customized baud rate. 0, 300-500000bps can be set. The default value is 9600bps. **Note: If some customer equipment is with non-standard baud rate, and it can customize the baud rate.**

M/S/F: Data bits: 7 bits and 8 bits are optional. The default value is 8 bits.

M/S/F: parity bit: none, odd, even, character, space is optional. The default is none.

M/S/F: Stop bit: 1 bit, 2 bit. The default is 1 bit.

M/S: Serial mode: RTU/ASCII mode is optional. The default is RTU mode.

M/S/F: character interval: interval for detecting the received message. 1.5t~2000t is optional. The default value is 5t. (T is the transmission time of a single character, which depends on the baud rate).

M/F: Response timeout (ms): The time that the master waits for the slave to respond after sending a command. 1~65535 is optional. The default value is 500.

M: Polling delay (ms): interval for sending Modbus commands (delay from receiving a response message to sending the next command). 0~65535 is optional. The default value is 10.

M: error handling method for reading commands: After the slave reading data timeout, the data processing method, hold last input value and clear the input value are optional. Default is holding the last input value.

M: Output mode: polling and event-triggered (data changes) are optional. Polling is the default mode. In polling mode, the Modbus periodically sends Write Message. In Event-triggered mode, Write Commands are sent only when the Modbus output data changes.

M: Module control: Disable and enable are optional. The default is disabled. To control the read/write commands of the Modbus, it can select Enable mode and control the read/write commands of the Modbus by controlling the value of Module Control Output.

M: Control mode: level trigger (continuous effective) and rising edge trigger (single trigger) are optional. The default is level trigger (continuous effective). This value is

valid only in module control enable mode.

M: first output data after power on (command): Enable and disable are optional. This default is enabled.

S: Slave ID: 1-247 can be set. This parameter is valid only in slave mode.

S: Response delay (ms): 0~65535 is optional. The default value is 50.

3.3 Converter read and write command module

3.3.1 Module in master mode

M: diagnosis module

M: read coil (0xxxx) supports 8 ~ 200bits optional

M: read the discrete input (1xxxx) supports 8 ~ 200bits optional

M: read input register (3xxxx) supports 1~125words optional

M: read hold register (4xxxx) supports 1~125words optional

M: write coil (0xxxx) supports single coil, 8~200bits optional

M: write hold register (4xxxx) supports single register, 1~125words optional

M: Diagnosis module: including module status input, module error code input, module control output, polling time input. The pop-down menu command must be added to the first 8 lines of the slot.

1. Module status input: 8 ~ 48 channels are available. The module status can monitor the working status of each data slot. When a data slot is faulty, the corresponding status bit will be set to 1.

2. Module error code input: 1-48 channels are available. When the data slot is faulty, the error code module can display the function code of the faulty channel and the specific error code. Users can judge the cause of the fault according to the error code, and then take corresponding adjustment methods. For detailed description, please see "Modbus Error Code Table".

3. Module control output: 8~48 channels are available. When the parameter (M:

module control) of the serial port is set to enable mode, the output control read and write channels of this command is effective.

4. Polling time: used to monitor the polling time of the serial port.

The slave input status of the module can monitor communication failures. For detailed description, please see "Modbus Error Code Table".

Modbus Error Code Table

Error Code	Fault description	Troubleshooting method
0x00	working properly	None
0x01	illegal function code	The device does not support the current function code. Select the corresponding function code module by referring to the slave manual
0x02	illegal data address	If the device data exceeds its address range, please modify the starting address or data length by referring to the slave manual
0x03	illegal data value	Data length error, the data length exceeds the max allowed value 125(Word) or 2000(Bit), please modify the data length
0x04	data processing error	Check if the range of data value meets slave requirements
0x05	the length of the application layer does not match	Increase the received character interval and check the communication parameter settings
0x06	protocol ID error	Check the sender message
0x07	buffer address error	Device internal error
0x08	bit offset error	Device internal error
0x09	The slave ID does not match	Increase the timeout period, check the hardware connection status and the communication parameter settings
0x0A	CRC error	CRC error, check the communication line
0x0B	LRC error	LRC error, check the communication line
0x0C	The response function code does not match	Check the hardware connection status
0x0D	The reply address does not match	Check the hardware connection status

0x0E	The reply data length does not match	Check the hardware connection status
0x0F	Communication timeout	Increase the timeout period, check the hardware connection status and the communication parameter settings
0x10	Error in ASCII mode start character	‘:’ The colon start character error
0x11	ASCII mode ending character error	CR/LF Error at end of carriage return newline
0x12	Non-character data in ASCII mode	The data contains non-hex ASCII code
0x13	ASCII mode character number error	The slave reply length is error

3.3.2 Module in slave mode

S: diagnosis module

S : read coil (0xxxx) supports 1~1024Bytes optional

S : read hold register (4xxxx) supports 1~512words optional

S : write coil (0xxxx) supports 1~1024Bytes optional

S : write the discrete input (1xxxx) supports 8~1024Bytes optional

S : write input register (3xxxx) supports 1~512words optional

S : write hold register (4xxxx) supports 1~512words optional

S: diagnosis module

3.3.3 Module in free port transparent transmission mode

F: Control and status module

F: The input and output data modules both support 1~512words optional

Process data definition of control and state module:

IO module data	Data name	Variable name	Data type	Byte offset
----------------	-----------	---------------	-----------	-------------

direction				
Input data	Output control word - feedback	Control_Word_Feedback	uint16_t	0
	Send frame length - feedback	Send_Data_Len_Feedback	uint16_t	2
	Serial port status	COM_Status	uint16_t	4
	Received error frame count	Error_Counter	uint16_t	6
	Total received data frame count	Received_Counter	uint16_t	8
	The current length of received frames in bytes	Received_Data_Len	uint16_t	10
Output data	Output control word	Control_Word	uint16_t	0
	Sent frame bytes length	Send_Data_Len	uint16_t	2

Variable Definition:

Variable Name	Bit15-6	Bit5	Bit4	Bit3	Bit2	Bit1	Bit0
Control_Word	Reserved	Received Counter Reset	Error Counter Reset	Timeout Error Reset	Parity Error Reset	Done Reset	Trigger
Send_Data_Len	Send_Data_Len						
COM_Status	Reserved			Timeout Error	Parity Error	Done	Busy
Error_Counter	Error_Counter						
Received_Counter	Received_Counter						
Received_Data_Len	Received_Data_Len						

Input Data Description:

1. Control_Word_Feedback indicates the feedback value of the output control word Control_Word. After the output control word is refreshed to the module, it will be updated to the control word feedback.

2. Send_Data_Len_Feedback is the feedback value of Send_Data_Len. After the

sending frame byte length is refreshed to the module, it will be updated to the sending frame byte length feedback.

3. In answer mode, the Busy bit is set to 1 when the serial port sends data.

3.1 When the serial port receives the answer within the timeout period, the Busy bit is cleared and the Done bit is 1. The Received_Counter count is increased by 1. If the received frame has a parity error, the Parity_Error bit is set to 1 and the Error_Counter count is increased by 1. The number of bytes in Received_Data_Len that holds the currently received frame.

3.2 If the serial port does not receive a response within the timeout period, Busy bit is cleared, Done complete bit is set to 1. Meanwhile, Timeout_Error is set to 1, Error_Counter error count is increased by 1, and Received_Data_Len is cleared.

4. In active reporting mode, the Received_Counter count is increments by 1 when the packet is received from the slave. If the received frame has a parity error, the Parity_Error bit is set to 1 and the Error_Counter count is increased by 1.

Output Data Description:

1. Received_Counter_Reset, when rising edge, the received count value

Received_Counter is cleared to 0 ;

Error_Counter_Reset, rising delay, Error_Counter is cleared to 0;

Timeout_Error_Reset, rising delay, Timeout_Error is cleared to 0,

Parity_Error_Reset, rising delay, Parity_Error is cleared to 0,

Done_Reset, Rising delay, Done is cleared to 0.


2. In active reporting mode, the Trigger bit is invalid and Send_Data_Len is invalid.

3. In the master/slave response mode, the Trigger ascending delay will trigger the serial port to send data once. The serial port sends data packets according to the data length of Send_Data_Len and waits for the response processing.


3.4 Modify the device name

3.4.1 Modify the device name in TIA

1.Power on Siemens PLC and ODOT-PNM02 V2.0. At the same time, use network cables to connect to the PC. Open the Portal software, click to the Oline access, find the local network card, double-click Update accessible devices, Siemens PLC and ODOT-PNM02 gateways will be searched.




2.double-click pnmb-address, then double-click the Online & diagnostics, under the Function, find the ProfiNet device name: modify the default name “pnmb-address” to “pnmb-1”, click the assign name. If the pnmb-1 appears in the menu of the local network card on the left, the device name has been modified. This name is used to access the module and assign the IP address to the module when configuring the device.




3.4.2 Modify the device name in Step7

1. Click "Options" → "Set PG/PC Interface", and select the communication interface as the network card connected to the gateway on the page of setting PG/PC interface.




2. Click "PLC" → "Edit Ethernet node", in the "Edit Ethernet node" page, click browse, in the "Browse network" page, it could see the scanned ODOT-PNM02 module, the default name of the module is "pnmb-address", select the module, click "flash", The "SF" light on the module flashes, which allows you to distinguish modules when there are multiple PNM modules in the network at the same time.




3. Select the module click "OK", the software will automatically write the MAC address of the selected module into the corresponding position of the "Edit Ethernet

node" page.





4. Modify the device name, click "Assign name", set a new device name for the gateway, the name will be used for programming configuration. Note: Changing the device name is mainly used when multiple ODOT-PNM02 modules exist on the network. If there is only one ODOT-PNM02 module on the network, it could directly use its factory default name pnmb-address in the subsequent configuration without changing the device name.




3.4.3 Modify the device name in STEP 7-MicroWIN SMART

Open the STEP 7-MicroWIN SMART software, click the Tools, click the Find PROFINET Devices, select local network card, all PROFINET devices are automatically scanned, the IP address and device name of the gateway could be viewed. Click Edit, set the gateway device name, and then click Settings.




3.5 Converter application topology


Topology diagram of master Mode



Topology diagram of slave mode



Topology of freed mode




4. Use in Siemens TIA V16


This chapter will be written with SIEMENS S7-1200 CPU1212 DC/DC/DC as the PROFINET Controller, TIA is used as the configuration software, this section provides an example of how to configure ODOT-PNM02.

4.1 Configuration of the MODBUS Master Mode


1. Find the XML folder in the product CD and make sure that the following files are in the folder. If not, please contact the supplier for them.




2. Open the TIA V16 software, click Create New Project, create a new project, named "PNM TEST".




3. Click Project view, "Online Access" to find the local network card, click Update accessible devices.




"PLC device IP Address" and "PNMNB-Address device IP Address" appear, click "Online & diagnostics" under the PNMB-address, it could set "ProfiNet device name" in the "Function" drop-down menu, which is used to access the gateway module in the later configuration.








4. Click "Add new device", select controller CPU 1212C DC/DC/DC (6ES7 212-1AG40-0XB0 V4.4), and click OK.




5. Click device configuration under PLC - "Network view", click PLC network port, and set the ProfiNet network and IP address of PLC PN port.




6. On the device configuration interface, click "Options" → "Manage general station description files (GSD)", select the path, find "GSDML-V2.33-ODOT-PNM02-L-20220107", and add the GSD file.




After success, click "Close" to exit the add GSD dialog box.




7. Click device configuration under PLC - "Network view". In the hardware directory, click other field devices → "PROFINET IO → Gateway → Odot Co., Ltd → Serial Gateway → Modbus Gateway", if the PNM02L V2.00 is found, the GSD file is successfully added.




8. Drag the module PNM02L V2.0 from the hardware directory into the Network view.




9. Connect the PNM02 gateway network to the PN interface of the S7-1200 PLC.




Select the PN port of the PNM02 gateway and click Ethernet address to set parameters. Set the gateway communication IP address and enter the "ProfiNet Device name" set before online access. **Note: The device name must be the same as the previous device.**



11. Double-click the gateway to enter Device view, select the gateway, and set the module parameters under General. (Set the parameters of the module with the M prefix).




12. Select a gateway in the Device view and select "Read/Write Command starting with M prefix " in the hardware directory on the right. When need to monitor the status of the module, it could first add "Diagnostic Modules". Note: not necessary.




M: Diagnostic modules: including module status input, module error code input, module control output, polling time input; The command of the diagnostic module must be added to the first eight lines of the slot; otherwise, an error will be reported when the command is downloaded.

Module status input: 8 to 48 channels are available. The module status could monitor the working status of each data slot. When a data slot is faulty, the corresponding status bit is set to 1 and automatically cleared after the fault is rectified.



Module error code input: There are 1-48 channels available. When the data slot fails,

the error code module could display the function code and specific error code of the error channel. Users could determine the cause of the fault according to the error code, and then take the corresponding adjustment method. For details, see Modbus Error Code Table.




Modbus Error Code Table

Error Code	Fault description	Troubleshooting method
0x00	working properly	None
0x01	illegal function code	The device does not support the current function code. Select the corresponding function code module by referring to the slave manual
0x02	illegal data address	If the device data exceeds its address range, please modify the starting address or data length by referring to the slave manual
0x03	illegal data value	Data length error, the data length exceeds the max allowed value 125(Word) or 2000(Bit), please modify the data length
0x04	data processing error	Check if the range of data value meets slave requirements
0x05	the length of the application layer does not match	Increase the received character interval and check the communication parameter settings

0x06	protocol ID error	Check the sender message
0x07	buffer address error	Device internal error
0x08	bit offset error	Device internal error
0x09	The slave ID does not match	Increase the timeout period, check the hardware connection status and the communication parameter settings
0x0A	CRC error	CRC error, check the communication line
0x0B	LRC error	LRC error, check the communication line
0x0C	The response function code does not match	Check the hardware connection status
0x0D	The reply address does not match	Check the hardware connection status
0x0E	The reply data length does not match	Check the hardware connection status
0x0F	Communication timeout	Increase the timeout period, check the hardware connection status and the communication parameter settings
0x10	Error in ASCII mode start character	‘:’ The colon start character error
0x11	ASCII mode ending character error	CR/LF Error at end of carriage return newline
0x12	Non-character data in ASCII mode	The data contains non-hex ASCII code
0x13	ASCII mode character number error	The slave reply length is error


Module control output: 8 to 48 channels are available. When parameter under the serial port (M: module control) is set to Enable mode, the output control read/write channel of the command is valid.

For example, if Q2.0=1, 03 in slot 5 reads 16 words. If Q2.0=0, 03 in slot 5 reads 16 words. This command is not executed. When Q2.1=1, 02 in slot 6 reads 96 bits. If Q2.1=0, 02 in slot 6 reads 96 bits. This command is not executed. And so on.




Note: The module control output function is activated. The read and write commands within the control range must be enabled.


Polling time input: used to monitor the polling time of the serial port. Note: Serial port 1 and serial port 2 are independent, so when need to use the two serial ports to collect data, add **two commands** to monitor the polling time respectively.




12. Gateway as the master, support Modbus function code 01/02/03/04/05/06/15/16. Add read and write commands for the hardware directory to the slot in the device overview.




13. After adding read and write commands, it needs to set module parameters for the commands. Ensure that the serial port number of the command is COM1 or COM2 (set to COM1 in this section), the ID of the slave, and the data start address.



14. At this time, the hardware configuration has been basically completed, save the project, compile. Check to see if the project is reporting errors, click download if there are no errors.



After the download is successful, open the monitoring table to monitor the data collected by the gateway. Using Modbus Slave to simulate devices on the RS485 serial port.




4.2 Configuration of the MODBUS Slave Mode

1→10 Refer to 1→10 in 4.1(Modbus Master).


11.Double-click the gateway to enter the Device view, select the gateway, and set the module parameters under the general parameters. (Set the parameters of the module with the S prefix)

Set the general parameter M/S/F: gateway operating mode to **Modbus Slave**.

S: slave ID: Set this parameter to 1.




12.Select a gateway in the Device view and select read and write commands starting with S prefix in the hardware directory on the right. When need to monitor the status of a module, it could add a diagnostic module. **Note: not necessary.**




S: Diagnostic module:


S: **Input status from the Modbus slave:** Indicates the processing of data packets sent from the Master of the current serial port.




13.As the slave, the gateway avoids the problem of overlapping addresses when customers use zone 0 and zone 4 output data, PN output data uses zone 1 and zone 3, and input data uses zone 0 and zone 4.




14. After the read and write commands are added, do not need to set module parameters for the read and write commands. For details about how to access the address, as follows: The address table corresponds to the read and write commands in the slot one by one. If multiple commands are used in the same address area, the address is automatically added later.



15. At this time the hardware configuration has been basically completed, save the project, compile and download.




16. After the download is successful, open the monitoring table. Modbus Poll is used to simulate the master RS485 device on the serial port RS485 side.




4.3 Configuration of the Freed Mode

1→10 Refer to 1→10 in 4.1(Modbus Master). The freed mode test uses the S7-1200 configuration test.

11.Double-click the gateway to enter the device view, select the gateway, and set the module parameters under the general parameters. M/S/F Serial port working mode: **Freed Mode**. (Set the parameters of the module with the F prefix)





12.Select a gateway in the Device view and select read and write commands starting with F prefix in the hardware directory on the right.




(1) Set the gateway to the **Report mode**, and connect gateway serial port 1 to the


debugging serial port tool to simulate field devices. The corresponding value changes could be monitored in the control and status module and the input data module.



(2) Set the gateway to **Request-Response** mode.



Set the output data length, when the control word Trigger is activated as 0-1 pulse, the gateway sends data to the serial port. **Note: The Trigger bit is activated once and the gateway sends data once.**




Through setting and debugging, PLC collects data from the serial port side through the gateway and stores it in the PLC address area, engineers parse the data format of uploaded messages and extract valid data for programming processing.

5. Use in STEP7 V5.5


In this chapter, SIEMENS 315-2 PN/DP is used as PROFINET Controller and Step7 is used as programming software to illustrate the use of PNM02. PLC, debug computer and PNM02 are connected to the same Ethernet network at first.

5.1 Configuration of the Modbus Master mode


1. Find the XML folder in the product CD and confirm whether the XML file of the gateway is in the folder. If not, please contact the supplier to obtain it.




2. Open the STEP7 software, click Create New project, create a new project, named "PNM_test".




3. Click "Options" → "Set PG/PC interface", and select the communication interface as the network card connected to the PLC on the page of setting PG/PC interface.




Click "PLC" → "Edit Ethernet node", in the "Edit Ethernet node" page, click "Browse", in the "Browse network" page the scanned ODOT-PNM02 module could be seen. The default name of the module is "PMB-address". Select the module, click "flash". The "SF" light on the module flashes, which allows to distinguish modules when there are multiple ODOT-PNM02 modules in the network at the same time.




Select a module and click "OK". The software will automatically write the MAC address of the selected module into the corresponding position on the "Edit Ethernet Node" page.




To modify the device name, click "Assign Name" and set a new device name for ODOT-PNM02, which will be used in the following configuration. Note: Changing the device name is mainly used when multiple ODOT-PNM02 modules exist on the network. If there is only one ODOT-PNM02 module on the network, do not change the device name of the Odot-PNM02 module, and directly use its default name "PMB-address" in the following configuration.




4. On the hardware configuration page of STEP7, click "Options" → "Install GSD file", click "Browse" in "Install GSD file" to select the path, find the folder where the XML file corresponding to ODOT-PNM02 resides, click "OK", select the XML file, and click "Install". Install the XML file of ODOT-PNM02 into STEP7.




5. On the STEP7 hardware configuration page, add the configuration controller, set the controller IP address, add the subnet, and click OK.



6. Select the subnet and double-click PNM02 under PROFINET IO→Additional Field
→Devices→Gateway→Serial Gateway→Modbus Gateway on the hardware catalog
page to configure the PNM02 gateway to the PROFINET network.




7. Select the ODOT-PNM02 device icon, enter the device name in the "General" TAB of the "Properties" page, which must be consistent with the module name set in Step 3, click "Ethernet", set the module IP address, and click "Confirm".




8. Select the ODOT-PNM02 device icon, double-click the first slot in the module slot information display section at the bottom of the software, and select the parameter

TAB in the pop-up property window to modify the ODOT-PNM02 module parameters.




9. Select the device icon of ODOT-PNM02, in the module slot information display section at the bottom of the software, select the slot, double-click the module under the module folder under PNM02 in the directory view, and insert the module into the slot.




The gateway serves as the master station and supports Modbus function code 01/02/03/04/05/06/15/16. Add read and write commands for the hardware directory to

the slot.




10. After adding the read and write command, double-click the command module, and set the parameters of the command module under the "Parameters" TAB on the "Properties" page. The value includes the serial port number (UART Num) COM1 or COM2, Slave ID, and Start Address of the Modbus slave.




11. At this time, the hardware configuration has been basically completed. Save and

compile the hardware configuration and download the project.




12. Right-click the command, click the "Monitor/Modify" option, and select "Monitor" on the "Monitor/Modify" page to monitor the communication data in real time, which is convenient for debugging (if the command is to write data, you can write the data to the slave Modbus device by clicking the "Modify value" button).



5.2 Configuration of the Modbus slave mode

1→7 Refer to 1→7 in section 5.1(Master Mode).

8. Select the ODOT-PNM02 device icon, double-click the first slot in the module slot information display section at the bottom of the software, and select the parameter TAB in the pop-up property window to modify the ODOT-PNM02 module parameters.




M/S/F: Gateway Mode: Set this mode to Modbus Slave.


S: Slave station ID: Set to 1 (gateway as Modbus RTU/ASCII slave station number is 1)

Serial port 1 and serial port 2 parameters refer to the master mode notes.

9. Select the ODOT-PNM02 device icon. In the Module slot information display section at the bottom of the software, select the slot, double-click the module in the module folder under PNM02 in the directory view, and insert the module in the slot (note: in the S folder).




The gateway, as the slave station, supports Modbus function code 01/02/03/04/15/16. Add the Modbus RTU/ASCII address command supported by the gateway to the slot.




10. After adding read and write commands, do not need to set module parameters for the read and write commands. The Modbus address range corresponding to each command is automatically generated according to the following rules:

The Modbus addresses corresponding to commands in the same Modbus data area are automatically added starting from 0 in the slot sequence. An example is as follows:




11. At this time the hardware configuration has been basically completed, save and compile, download.



12. Right-click the command, click "Monitor/Modify" option, select "Monitor" on the "Monitor/Modify" page, it could monitor the communication data in real time, this


function could be convenient debugging (if the command is to write data, click the "modify value" button to write the data).




5.3 Configuration of the Freed mode

1→7 Refer to 1→7 in section 5.1(Master Mode).


8. Select the ODOT-PNM02 device icon, double-click the first slot in the module slot information display section at the bottom of the software, and select the parameter TAB in the pop-up property window to modify the ODOT-PNM02 module parameters. (Set the parameters of the module with an F prefix.) The device configuration parameters are as follows: M/S/F: Gateway Working mode Select the freed mode.




11. Select the ODOT-PNM02 device icon. In the Module slot information section under the software, select the slot, double-click the module in the module folder under PNM02 in the hardware directory view on the right, and insert the module into the slot. (Select the command starting with F)



12. Set the gateway to the active reporting mode, and connect the gateway serial port 1 to the debugging serial port tool to simulate the field devices (such as the scanning gun and weighing instrument). Save, download. The corresponding value changes could be monitored in the control and status module and the input data module.






6. Use in Siemens STEP 7-MicroWIN SMART



Note: The S7-200SMART CPU firmware version is only supported by PROFINET communication at V2.4 and above, and the STEP 7-MicroWIN SMART programming software version is supported by PROFINET communication at V2.4 and above. If the CPU or programming software version is lower than V2.4 and want to do PROFINET communication, please upgrade the CPU firmware version and download the higher version of the programming software on the Siemens website.

6.1 Configuration of the Modbus Master mode


1. Open the STEP 7-MicroWIN SMART software, click the file, click GSDML management, and in the pop-up interface, find the directory where the GSD file of ODOT-PNM02 is located, and click confirm.



2. Click Find PROFINET devices, select the local network card, and all PROFINET devices will be automatically scanned, and the IP address and device name of the gateway could be viewed. Click Edit to set the gateway device name.




3. Click Tools, click PROFINET, in the pop-up PROFINET configuration interface, select the PLC role is Controller, set the IP address of the PLC, and click Next.




4. In the pop-up interface, select PNM02L in the directory bar on the right, and click the Add button in the lower left corner to add the gateway to the PROFINET bus of the PLC. It could change the IP address and device name of the gateway.


Note: The device name must be the same as the device name that was scanned or modified.




5. Select the PNM02 V2.0V4.0 to modify the working mode and serial port parameters, in this section, test in Master mode.




6. Select the PNM02L V2.0V4.0-pnmb-1, add the read/write commands and the Module Error Code Input(06CH).




7. For each read/write command, it could modify the serial port, slave ID and start address. The first four commands use the default values, modify the start address of the sixth commands as 50, and modify the start address of the seventh commands as 50. Click the generate, the configuration of PNM02 Master mode is complete.




8. Save, compile and download.






9. When the program is running, it could use the state chart to read, write, monitor, and force the variables in it.




10. Modbus Slave is used to simulate the RS485 device. Click the online of the STEP 7-Micro/WIN SMART software, click the status icon to monitor the data on the RS485 device.





6.2 Configuration of the Modbus Slave mode

1. Open the STEP 7-MicroWIN SMART software, click the file, click GSDML management, and in the pop-up interface, find the directory where the GSD file of ODOT-PNM02 is located, and click confirm.




2. Click Find PROFINET devices, select the local network card, and all PROFINET devices will be automatically scanned, and the IP address and device name of the gateway could be viewed. Click Edit to set the gateway device name.






3. Click Tools, click PROFINET, in the pop-up PROFINET configuration interface, select the PLC role is Controller, set the IP address of the PLC, and click Next.




4. In the pop-up interface, select PNM02L in the directory bar on the right, and click the Add button in the lower left corner to add the gateway to the PROFINET bus of the PLC. It could change the IP address and device name of the gateway.


Note: The device name must be the same as the device name that was scanned or

modified.




5. Select the PNM02 to modify the working mode and serial port parameters, in this section, the working mode is Modbus Slave, the Slave ID is 6.







6. Select the PNM02L V2.0V4.0-pnmb-2, add the slave mode read and write command on the right to the slot, click the Generate, complete the configuration of the gateway PNM02 slave mode.




7. Save, compile, and download.



8. When the program is running, it could use the state chart to read, write, monitor, and force the variables in it.



9. Use Modbus Poll to simulate the RS485 master equipment in the field. STEP 7-Micro/WIN SMART software could be run online, and the status chart monitoring button could be clicked to monitor the data on the RS485 side.



6.3 Configuration of the Freed mode

6.3.1 The introduction of Freed mode

In the Freed mode, it is divided into control and status module and input and output data module.

(1) The control and status module need to set the serial port and unvarnished transmission type. Communication mode : report mode, request-response mode, report & request-response mode.

(2) Input/output data module, only need to set the serial port number.

Process data definition of control and state module:

IO module data direction	Data name	Variable name	Data type	Byte offset
Input data	Output control word - feedback	Control_Word_Feedback	uint16_t	0
	Send frame length - feedback	Send_Data_Len_Feedback	uint16_t	2
	Serial port status	COM_Status	uint16_t	4
	Received error frame count	Error_Counter	uint16_t	6
	Total received data frame count	Received_Counter	uint16_t	8
	The current length of received frames in bytes	Received_Data_Len	uint16_t	10
Output data	Output control word	Control_Word	uint16_t	0
	Sent frame bytes length	Send_Data_Len	uint16_t	2

Variable Definition:

Variable Name	Bit15-6	Bit5	Bit4	Bit3	Bit2	Bit1	Bit0
Control_Word	Reserved	Received Counter Reset	Error Counter Reset	Timeout Error Reset	Parity Error Reset	Done Reset	Trigger
Send_Data_Len	Send_Data_Len						
COM_Status	Reserved			Timeout Error	Parity Error	Done	Busy
Error_Counter	Error_Counter						
Received_Counter	Received_Counter						

Received_Data_Len	Received_Data_Len
-------------------	-------------------

Input Data Description:

1. Control_Word_Feedback indicates the feedback value of the output control word Control_Word. After the output control word is refreshed to the module, it will be updated to the control word feedback.
2. Send_Data_Len_Feedback is the feedback value of Send_Data_Len. After the sending frame byte length is refreshed to the module, it will be updated to the sending frame byte length feedback.
3. In answer mode, the Busy bit is set to 1 when the serial port sends data.
 - 3.1 When the serial port receives the answer within the timeout period, the Busy bit is cleared and the Done bit is 1. The Received_Counter count is increased by 1. If the received frame has a parity error, the Parity_Error bit is set to 1 and the Error_Counter count is increased by 1. The number of bytes in Received_Data_Len that holds the currently received frame.
 - 3.2 If the serial port does not receive a response within the timeout period, Busy bit is cleared, Done complete bit is set to 1. Meanwhile, Timeout_Error is set to 1, Error_Counter error count is increased by 1, and Received_Data_Len is cleared.
4. In active reporting mode, the Received_Counter count is increments by 1 when the packet is received from the slave. If the received frame has a parity error, the Parity_Error bit is set to 1 and the Error_Counter count is increased by 1.


Output Data Description:

1. Received_Counter_Reset, when rising edge, the received count value Received_Counter is cleared to 0 ;
Error_Counter_Reset, rising delay, Error_Counter is cleared to 0;
Timeout_Error_Reset, rising delay, Timeout_Error is cleared to 0,
Parity_Error_Reset, rising delay, Parity_Error is cleared to 0,
Done_Reset, Rising delay, Done is cleared to 0.
2. In active reporting mode, the Trigger bit is invalid and Send_Data_Len is invalid.


3. In the master/slave response mode, the Trigger ascending delay will trigger the serial port to send data once. The serial port sends data packets according to the data length of Send_Data_Len and waits for the response processing.

6.3.2 Configuration of Freed mode


1. Open the STEP 7-MicroWIN SMART software, click the find PROFINET Devices, select the local network card, and all PROFINET devices will be automatically scanned, and the IP address and device name of the gateway could be viewed. Click Edit to set the gateway device name.





2. Click Tools, click PROFINET, in the pop-up PROFINET configuration interface, select the PLC role is Controller, set the IP address of the PLC, and click Next. In the pop-up interface, select PNM02L V2.0V4.0 in the directory bar on the right, and click the Add button in the lower left corner to add the gateway to the PROFINET bus of the PLC. It could change the IP address and device name of the gateway.




Select the PNM02 to modify the working mode and serial port parameters, in this section, the working mode is Freed mode




Select the PNM02L V2.0V4.0-pnmb-2, add the read and write commands in Freed mode on the right to the slot. Set the communication mode as report, click the generate, complete the configuration of Freed mode.




Set the communication mode as report, Serial Port Utility is used to simulate RS485 equipment. After compiling and downloading, it could monitor the corresponding value changes in the chart status control and status module and input data module.



Set the communication mode as request-response.



Set the send byte length to 8. When the control word Trigger is activated as 0-1 pulse, the gateway sends data to the serial port. **Note: The Trigger bit is activated once and the gateway sends data once.**




7. Firmware upgrades


The gateway supports network port upgrade, and when the module firmware is updated, the module firmware needs to be upgraded.

Upgrade software: IO Config


1. after the installation is complete, open the software, click the Tools——Search the devices or shortcut icon, in the pop-up window, select the local network card, Click the Search, in the list of Devices, select a device with PN-MBL V2.0 and click Update.





Or click Device Upgrade  Device Update, select Network Port for the interface, the IP address of the device:192.168.0.254. Click Read Info to read the internal firmware information of the gateway.



Click , in the pop-up interface, select the new firmware file and click to open, the new firmware information will be displayed in the lower left corner.



Select the 0# coupler, hit "✓", click to start the upgrade, and click to run the APP when finished. Or select Auto Jump (to APP) and click to start the upgrade.



8. Appendix

8.1. Modbus-RTU Introduction to Agreement

For you, you only need to understand that Modbus has 8 important function codes corresponding to 4 areas: 4 for reading, 2 for writing a single bit or register, and 2 for writing multiple bits or multiple registers. (Address description uses PLC address)

8.2 Modbus Storage area

The storage area of the controller (or Modbus device) involved in Modbus is identified by 0XXXX, 1XXXX, 3XXXX, 4XXXX.

Store ID	Name	type of data	Read/write	Storage unit address
0XXXX	Output coil	Bit	Read/write	00001~0XXXX, XXXX: Related to equipment
1XXXX	Discrete input	Bit	Read only	10001~1XXXX, XXXX: Related to equipment
3XXXX	Input register	word	Read only	30001~3XXXX, XXXX: Related to equipment
4XXXX	Output/hold ing register	word	Read/write	40001~4XXXX, XXXX: Related to equipment

8.3 Modbus function code

The Modbus message is relatively fixed, so you only need to understand it a little bit. After reading a few messages, you will know its structure, and you can inquire about it when you need it.

(1) Read output coil status

Function code: 01H

Master query message format:

address	function code	Start address high	Start address low	High number of coils	Low number of coils	CRC
---------	------------------	--------------------------	-------------------------	----------------------------	------------------------	-----

0x11	0x01	0x00	0x13	0x00	0x25	xxxx
------	------	------	------	------	------	------

Function: Read the 0XXXX status of the slave output coil.

Note: The start address of the coil of some equipment is 00000, which corresponds to the address 00001 in the equipment, which is sequentially extended.

This example: read the output coil of slave station 0x11, the register start address is 0x13=19, the number of coils is 0x0025H=37; therefore, the function of this query message is: read 0x11(17) slave station output coil 00019—00055, A total of 37 coil states.

Slave response format:

Function: Slave machine returns to output coil 0XXXX state

address	function code	Byte count	Coil state 19-26	Coil state 27-34	Coil state 35-42	Coil state 43-50	Coil state 51-55	CRC
0x11	0x01	0x05	0xCD	0x6B	0xB2	0x0E	0x1B	xxxx

(2) Read discrete input state

Function code: 02H

Master inquiry message format:

address	function code	Start address high	Start address low	High number of coils	Low number of coils	CRC
0x11	0x02	0x00	0xC4	0x00	0x16	xxxx

Function: Read the status of the slave input coil 1XXXX.

Note: The start address of some equipment coils is 10000, which corresponds to the address 10001 in the equipment, which will be extended sequentially.

This example: read the input coil of slave station 0x11, the starting address is 0x00C4=196, and the number of coils is 0x0016=22.

Therefore, the function of this inquiry message is: read 0x11 (17) slave station input coil 10196-10217, a total of 22 discrete input states.

Slave response format:

address	function code	Byte count	DI 10196-10203	DI 10204-10211	DI 10212-10217	CRC
0x11	0x02	0x03	0xAC	0xDB	0x35	xxxx

Function: Slave machine returns to input coil 1 XXXX state

(3) Read output/holding register

Function code: 03H

Master inquiry message format:

address	function code	Register start address high	Register start address low	High register number	Low register number	CRC
0x11	0x03	0x00	0x6B	0x00	0x03	xxxx

Function: Read the value of the slave holding register 4XXXX.

Note: Some device registers start address 40000 corresponds to 40001 address in the device, and it is postponed sequentially.

This example: read the value of the holding register of the slave station 0x11, the starting address is 0x006BH=107, and the number of registers is 0x0003; therefore, the function of this query message is: reading the 3 holding registers 40107-40109 of the slave No. 0x11 (17H) value

address	function code	byte count	register 40107 high	register 40107 low	register 40108 high	register 40108 low	register 40109 high	register 40109 low	CRC
0x11	0x03	0x06	0x02	0x2B	0x01	0x06	0x2A	0x64	xxxx

Function: The slave returns the value of the holding register: (40107) =0x022B,

(40108) =0x0106, (40109) =0x2A64

(4) Read the input register

Function code: 04H

Master inquiry message format:

address	function code	Register start address high	Register start address low	High register number	Low register number	CRC
---------	---------------	-----------------------------	----------------------------	----------------------	---------------------	-----

0x11	0x04	0x00	0x08	0x00	0x01	xxxx
------	------	------	------	------	------	------

Function: Read the value of slave station input register 3XXXX.

Note: In some devices, the register start address 30000 corresponds to the address 30001 in the device, and it is extended sequentially.

This example: Reading the value of the input register of slave station 0x11, starting at 0x0008H Note: In some devices, the starting address of the register 30000

corresponds to the address 30001 in the device, and it is extended sequentially.

This example: read the input register value of slave station 0x11, the starting place is 0x0008H, and the register number is 0x0001;

Therefore, the function of this query message: read the value of 1 input register 30008 of slave station 0x11 (17); the number of registers is 0x0001;

Therefore, the function of this query message: read the value of 1 input register 30008 of slave station 0x11 (17);

Slave response format:

addresses	function code	Byte count	Input register 30008 high	Input register 30008 low	CRC
0x11	0x04	0x02	0x01	0x01	xxxx

Function: Slave station returns the value of input register 30008; (30008) = 0x0101

(5) Force a single coil

Function code: 05H

Master inquiry message format:

addresses	function code	coil address high	coil address low	Disconnect mark	Disconnect mark	CRC
0x11	0x05	0x00	0xAC	0xFF	0x00	xxxx

Function: Force the value of 0x01(17) slave coil 0XXXX. In some devices, the coil start address 00000 corresponds to the address 00001 in the device, which is sequentially extended.

Disconnect mark=FF00, Set coil ON。

Disconnect mark=0000, Set coil OFF。

Example: The starting address is 0x00AC=172. Force the No. 17 slave coil 0172 to ON.

Response format: original text return

Function: Force No. 17 slave coil 0172 ON to return the original text

(6) Preset single holding register

Function code: 06H

address	function code	Coil address high	Coil address low	Disconnect mark	Disconnect mark	CRC
0x11	0x05	0x00	0xAC	0xFF	0x00	xxxx

Master inquiry message format:

address	function code	coil address high	Register start address low	register number high	register number low	CRC
0x11	0x06	0x00	0x87	0x03	0x9E	xxxx

Function: Preset order to hold the value of register 4XXXX. In some devices, the coil start address of 40000 corresponds to the address of 40001 in the device, which is sequentially extended.

Example: preset the single holding register 40135 of No. 17 slave to 0x039E;

Response format: original text return

address	function code	coil address high	register start address low	register number high	register number low	CRC
0x11	0x06	0x00	0x87	0x03	0x9E	xxxx

Function: Preset No. 17 slave single holding register 40135 as 0x039E and return to the original text.

(7) Forced multiple coils

Function code: 0FH

Master inquiry message format:

address	function code	coil start address high	coil start address low	number of coils high	number of coils low	Byte count	Coil state 20-27	Coil state 28-29	CRC
0x11	0x0F	0x00	0x13	0x00	0x0A	0x02	0xCD	0x00	xxxx

Function: Force multiple continuous coils 0XXXX to ON/OFF state.

Note: In some devices, the coil start address 00000 corresponds to the address 00001 in the device, which is sequentially extended.

In this example: force multiple continuous coils from the slave station of No. 0x11, the start address of the coil is 0x0013=19, and the number of coils is 0x000A=10

Therefore, the function of this query message is: force the value of 0x11(17) slave station 10 coils 00019-00028; CDH→00019-00026; 00H→00027-00028;

Slave response format:

address	function code	High bit of coil start address	Low bit of coil start address	High number of coils	Low number of coils	CRC
0x11	0x0F	0x00	0x13	0x00	0x0A	xxxx

(8) Preset multiple registers

Function code: 10H

Master inquiry message format:

address	function code	Start register address high	Start register address low	register number high	register number low	Byte count	Data high	Low-level data	Data high	Data low	CRC
0x11	0x10	0x00	0x87	0x00	0x02	0x04	0x01	0x05	0x0A	0x10	xxxx

Function: preset multiple holding register values 4XXXX of the slave.

Note: In some devices, the starting address of the holding register 40000 corresponds to the address 40001 in the device, which is extended in turn.

This example: preset multiple holding register values of slave station 0x11, the starting address of the register is 0x0087=135, and the number of coils is 0x0002=2.

Therefore, the function of this query message is: preset the values of 2 holding registers of the slave station of No. 0x11 (17); 0105H→40135; 0A10H→40136.

Response format:

addresses	function code	Start register address high	Start register address Low	register number high	register number Low	CRC
0x11	0x10	0x00	0x87	0x00	0x02	xxxx

8.2. Brief introduction of serial network topology

8.2.1 RS232

RS232 is one of the serial communication interfaces of industrial control, and it is widely used to connect computer serial interfaces and peripherals. RS232 uses a signal line and a signal return line to form a common ground transmission form. The three-wire connection method can realize full-duplex communication. The transmission signal is a single-ended signal. This common ground transmission is prone to common mode interference. Therefore, the anti-noise interference is weak and the transmission distance is limited. The RS232 interface standard stipulates that the maximum transmission distance standard value is 50 feet (approximately 15 meters) when the symbol distortion is less than 4%. (Long-distance communication above 15m needs to be adopted Modem), the maximum transmission distance is also related to the communication baud rate. In actual use, if the transmission distance is far, please lower the baud rate. In order to reduce the external electromagnetic interference during signal transmission, please use shielded cables as communication cables.

The RS232 interface standard stipulates on TXD and RXD:

RS232 uses negative logic to transmit signals, and takes $-(3\sim 15)V$ signal as logic "1"; takes $+(3\sim 15)V$ signal as logic "0"; voltage between $-3\sim +3V$ It is meaningless, and a voltage lower than $-15V$ or higher than $+15V$ is also meaningless.

RS232 interface classification:

DB9 male connector




The upper left corner is 1, the lower right corner is 9

9-pin RS232 serial port (DB9)

PIN	Name	Effect
1	CD	Carrier detect
2	RXD	Receive data
3	TXD	Receive data
4	DTR	Data terminal is ready
5	GND	Signal ground
6	DSR	Data ready
7	RTS	Request to send
8	CTS	Clear to send
9	RI	Ring alert

Because the RS232 interface has the above-mentioned electrical characteristics, it can only realize point-to-point communication.

The RS232 communication wiring diagram is shown in the figure:



8.2.2 RS422

The full name of RS422 interface standard is "Electrical Characteristics of Balanced Voltage Digital Interface Circuit", which defines the characteristics of the interface circuit. RS422 adopts four-wire plus ground wire (T+, T-, R+, R-, GND), full-duplex, differential transmission, multi-point communication data transmission protocol. It adopts balanced transmission and adopts unidirectional/non-reversible transmission line with or without enabling end. Because the receiver adopts high input impedance and the transmission driver has stronger driving ability than RS232, it is allowed to connect multiple receiving nodes on the same transmission line, up to 10 nodes can be

connected. That is, a master device (Master), and the rest are slave devices (Slave).

The slave devices cannot communicate, so RS-422 supports point-to-many two-way communication.

The maximum transmission distance of RS-422 is 4000 feet (about 1219 meters), and the maximum transmission rate is 10Mb/s. The length of the balanced twisted pair is inversely proportional to the transmission rate, and the maximum transmission distance is only possible when the rate is below 100kb/s. Only in a short distance can the highest transmission rate be obtained. Generally, the maximum transmission rate that can be obtained on a 100-meter-long twisted pair cable is only 1Mb/s.

RS-422 needs to be connected to a terminal resistor, and its resistance is required to be approximately equal to the characteristic impedance of the transmission cable. In short-distance transmission, no terminating resistor is needed, that is, no terminating resistor is generally required below 300 meters. The terminating resistor is connected to the far end of the transmission cable.

In the one-master-multi-slave network connection, the sending ends of all slave stations are connected to the receiving end of the last connected to the master station through a daisy chain; the receiving ends of all slaves are connected to the last connected to the master station through a daisy chain. Sender.


RS422 pin definition:

RS422 (9Pin)		effect	Remarks
3	R-	Receiving negative	Must connect
2	T-	Send negative	Must connect
7	R+	Receiving positive	Must connect
8	T+	Send positive	Must connect



The upper left corner is 1, the lower right corner is 9

The RS422 communication wiring diagram is shown in the figure:



8.2.3 RS485

Since RS-485 is developed on the basis of RS-422, many electrical regulations of RS-485 are similar to RS-422. For example, balanced transmission methods are adopted, and terminating resistors are required to be connected to the transmission line. RS-485 can adopt two-wire and four-wire methods, and the two-wire system can realize true multi-point two-way communication.

RS485 is a standard that defines the electrical characteristics of drivers and receivers in a balanced digital multipoint system. It uses a combination of balanced drivers and differential receivers to enhance the ability to resist common mode interference, that is, to resist noise interference. Since the half-duplex network composed of RS485 interface generally adopts two-wire connection mode, and uses differential signals to transmit data, the voltage difference between the two wires is $-(2\sim6)V$, which means logic "0", the voltage difference between the two wires $+(2\sim6)V$ means logic "1".

The RS485 signal transmission distance is related to the communication baud rate. The higher the baud rate, the shorter the transmission distance. When the baud rate is not higher than 100Kbps, the theoretical maximum communication distance is about 1200 meters. In actual use, due to Factors such as electromagnetic interference often fail to reach the maximum communication distance. If you are communicating over a longer distance, please lower the baud rate. To reduce the signal's electromagnetic


interference during transmission, please use twisted-pair shielded cables as communication cables.

The RS485 bus supports a maximum of 32 nodes without relays. The nodes are connected by a "daisy chain" connection. Terminal resistors are required at both ends of the communication cable, and the resistance is required to be approximately equal to the characteristics of the transmission cable. impedance. In short-distance transmission, no terminating resistor is needed, that is, no terminating resistor is generally required below 300 meters. The terminating resistor is connected to the two ends of the transmission cable.

RS485 9-pin pin definition:

Pin	Name	Effect	Note
1	Data-/B-/485-	Send positive	Must connect
2	Data+/A+/485+	Receiving positive	Must connect
5	GND	Ground wire	

The RS485 communication wiring diagram is shown in the figure:



Odot Automation System Co., Ltd.

Add: No.6 Hongsheng Road, Hi-Tech District, Mianyang, Sichuan, China.



Tel: +86-0816-2538289

Zip Code: 621000

Email: sales@odotautomation.com

Web: www.odotautomation.com